

APPLICATION CHART

DF4/6 '03 - Current

| | |
|------------------------------|---------------------------------|
| Side Mount Control Box | 67200-94120 |
| Remote Control Attaching Kit | 67130-93102 |
| Rectifier Set | 32801-91101 |
| Water Pump Repair Kit | 17400-98661 '03 - '10 |
| | 17400-98661 '11 - Curr |
| Battery Charging Kit | 32000-91101 |
| Receptacle | 39800-91100 |
| Spark Plug | BPR6E 09482-00299 '03 - '10 |
| Spark Plug | DCPR6E-9 09482-00104 '11 - Curr |



DF9.9A '10 - Current

| | |
|------------------------------|------------------------|
| Side Mount Control Box | 67200-91120 |
| Remote Control Attaching Kit | 67130-99100* |
| Water Pump Repair Kit | 17400-99101 |
| Electric Starter Set | 31000-99100 |
| Battery Charging Kit | 32000-99100 |
| Oil Filter | 16510-05240 '10 |
| | 16510-45H10 '11 - Curr |
| Drag Link | 67701-99102 |
| Propeller Hardware Kit | 57630-99100 |
| Spark Plug | CKE 09482-00528 |

*Clamp Bracket Set 42100-99100-02P required to install.



DF9.9/15 '96 - Curr

| | | |
|------------------------------|------------------|------------|
| Side Mount Control Box | 67200-91120 | '05 - Curr |
| Remote Control Attaching Kit | 67130-94111 | '05 - Curr |
| Remote Control Cables | 99105-11002-0XX* | 2 req'd |
| Harness, Remote Control | 36630-89E02*** | '96 - '04 |
| Main Harness | 36620-94101 | '05 - Curr |
| Water Pump Repair Kit | 17400-93951 | '96 - '06 |
| | 17400-94100 | '07 - Curr |
| Steering Bracket Attachment | 67720-93E00 | |
| Tilt-Tube Attachment | 41141-89E00 | |
| Rectifier Set | 32800-95D01 | '96 - '04 |
| | 32800-94111 | '05 - Curr |
| Rectifier Regulator | 32801-94101 | '05 - Curr |
| Battery Charging Kit | 32000-94101 | '05 - Curr |
| Optional Lighting Coil Set | 32120-93E10 | '96 - '04 |

| | | |
|--------------------------|-----------------------|------------|
| Choke Solenoid | 38610-93E00 | '96 - '04 |
| Bolts | 01550-06167 | 2 req'd |
| Starter Motor Set | 31101-95D20-0EP | '96 - '03 |
| | 31100-94J22 | '05 - Curr |
| Stator, 120W | 32120-94J10 | '06 - Curr |
| Flywheel, Ring Rear Type | 32102-94J10 | '05 - Curr |
| Propeller Hardware Kit | 57630-93900 | |
| Drag Link Assembly | 67701-93E12 | '97 - Curr |
| | 67701-941A0 | 9.5T Curr |
| Spark Plug | DCPR6E 09482-00446 | up to '04 |
| | BKR6E 09482-00427 | '04 - Curr |
| | CPR6-EA-9 09482-00104 | '11 - Curr |
| Oil Filter | DF9.9/15 16510-05240 | '96 - Curr |
| | DF9.9/15 16510-45H10 | '11 - Curr |



DF9.9B/15A/20A '12 - Current

| | |
|------------------------------|-------------------------|
| Side Mount Control Box | 67200-93113 |
| Single Binnacle Kit | 67000-93105 |
| Flush Mount Kit | 67000-93126 |
| Remote Control Attaching Kit | 67130-95102 DF9.9B/15A |
| | 67130-89L04 DF20A |
| Remote Control Cables | 99105-11002-0XX* 2req'd |
| Single Binnacle | 67200-93113 |
| Flush Mount | 67200-93132 |
| Wire Harness 16' | 36620-93152 |
| Wire Harness 21' | 36620-93162 |
| Wire Harness 26' | 36620-93182 |
| Ignition Sw. Panel Assy | 37100-96100 |
| Eng. Sw. Emp. Stop/Buzzer | 37100-96124 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93104 |
| Water Pump Repair Kit | 17400-94100 |
| Drag Link Kit | 67700-95101 |
| Propeller Hardware Kit | 57630-93900 |
| Spark Plug | DCPR6E 09482-00446 |



DF25/30 '06 - Current

| | |
|------------------------------|-------------------------|
| Side Mount Control Box | 67200-91120 |
| Single Binnacle Kit | 67000-93105 |
| Flush Mount Kit | 67000-93126 |
| Remote Control Attaching Kit | 67130-95102 |
| Remote Control Cables | 99105-11002-0XX* 2req'd |
| Single Binnacle | 67200-93113 |
| Dual Binnacle | 67200-93123 |
| Flush Mount | 67200-93132 |
| Wire Harness 16' | 36620-93152 |
| Wire Harness 21' | 36620-93162 |
| Wire Harness 26' | 36620-93182 |
| Ignition Sw. Panel Assy | 37100-96100 |
| Eng. Sw. Emp. Stop/Buzzer | 37100-96124 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93104 |
| Water Pump Repair Kit | 17400-95102 |
| Drag Link Kit | 67700-95101 |
| Propeller Hardware Kit | 57630-96300 |
| Spark Plug | BKR6E 09482-00427 |



SPECIFIC APPLICATION NOTES: * Cable is available in one foot increments from 8 to 29 feet. (example: 008 = 8 ft, 025 = 25 ft)
 ** Must use with one of the following Main Harnesses: 16': 36620-93152 21': 36620-93162 25': 36620-93182
 *** Under-Hood Electric Start Harness

APPLICATION CHART



DF40A/50A/50AV/60A/60AV '10-Current

| | |
|---------------------------|--------------------------|
| Side Mount Control Box | 67200-93150** |
| Single Binnacle Kit | 67000-93105 |
| Dual Binnacle Kit | 67000-93115 |
| Flush Mount Kit | 67000-93126 |
| Remote Control Cables | 99105-11002-0XX* 2 req'd |
| Single Binnacle | 67200-93113 |
| Dual Binnacle | 67200-93123 |
| Flush Mount | 67200-93132 |
| Wire Harness 16' | 36620-93152 |
| Wire Harness 21' | 36620-93162 |
| Wire Harness 26' | 36620-93162 |
| Power Trim/Tilt Sw. | 37805-93100 |
| Ignition Sw. Panel Assy. | 37100-96100 |
| Dual Ign. Sw. Panel Assy. | 37100-96114 |
| Ing. Sw. Emg. Stop/Buzzer | 37100-96124 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93104 |
| Dual Engine Tie Bar | 99105-10006 |

| | |
|-----------------------------|---------------------------|
| Steering Tensioner | 43770-09E03 |
| Water Pump Repair Kit | 17400-98L00 |
| Tiller Handle Kit | 63002-88L07-0EP |
| Tiller Handle Kit with Tach | 63002-88L12-0EP DF40A/50A |
| | 63002-88L12-0EP DF60A |
| Drag Link Kit | 67701-87111 |
| Propeller Hardware Kit | 57630-90J00 |
| Propeller Hardware Kit | 57630-90J00 DF50AV/60AV |
| Spark Plug | DCFR6E 09482-00446 |

DF115/115A/140/140A '01-Current

| | |
|-----------------------------|--------------------------|
| Side Mount Control Box | 67200-93150** |
| Single Binnacle Kit | 67000-93105 |
| Dual Binnacle Kit | 67000-93115 |
| Flush Mount Kit | 67000-93126 |
| Remote Control Cables | 99105-11002-0XX* 2 req'd |
| Single Binnacle | 67200-93113 |
| Dual Binnacle | 67200-93123 |
| Flush Mount | 67200-93132 |
| Wire Harness 16' | 36620-93152 |
| Wire Harness 21' | 36620-93162 |
| Wire Harness 26' | 36620-93162 |
| Power Trim/Tilt Sw. | 37805-93100 |
| Ignition Sw. Panel Assy. | 37100-96100 |
| Dual Ign. Sw. Panel Assy. | 37100-96114 |
| Ing. Sw. Emg. Stop/Buzzer | 37100-96124 |
| Warning Buzzer | 38500-93100 '01-'04 |
| | 38500-92X50 '05-Current |
| Emergency Stop Assy. | 37803-93104 |
| Dual Engine Tie Bar | 99105-10006 |
| Water Pump Repair Kit | 17400-90J20 '01-'05 |
| | 17400-92J00 '06-'08 |
| | 17400-92J21 '09-Current |
| Tiller Handle Kit | 63002-90J29-0EP |
| Tiller Handle Kit with Tach | 63002-90J32-0EP DF115A |
| Drag Link Kit | 67701-90J01 '01-'10 |
| Propeller Hardware Kit | 57630-90J00 |
| Spark Plug | BKRE 09482-00427 |

DF70A/90A '09-Current

| | |
|------------------------|--------------------------|
| Side Mount Control Box | 67200-93150** |
| Single Binnacle Kit | 67000-93105 |
| Dual Binnacle Kit | 67000-93115 |
| Flush Mount Kit | 67000-93126 |
| Remote Control Cables | 99105-11002-0XX* 2 req'd |
| Single Binnacle | 67200-93113 |
| Dual Binnacle | 67200-93123 |
| Flush Mount | 67200-93132 |
| Wire Harness 16' | 36620-93152 |
| Wire Harness 21' | 36620-93162 |
| Wire Harness 26' | 36620-93162 |
| Power Trim/Tilt Sw. | 37805-93100 |

| | |
|-----------------------------|-----------------------------|
| Ignition Sw. Panel Assy. | 37100-96100 |
| Dual Ign. Sw. Panel Assy. | 37100-96114 |
| Ing. Sw. Emg. Stop/Buzzer | 37100-96124 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93104 |
| Dual Engine Tie Bar | 99105-10006 |
| Water Pump Repair Kit | 17400-87L01 |
| Tiller Handle Kit | 63002-87L05-0EP '09-Current |
| Tiller Handle Kit with Tach | 63002-87L13-0EP |
| Drag Link Kit | 67701-87L01 |
| Propeller Hardware Kit | 57630-90J00 |
| Spark Plug | DCFR6E 09482-00446 |

DF115/175 '06-Current

| | |
|---------------------------|--------------------------|
| Side Mount Control Box | 67200-93150** |
| Single Binnacle Kit | 67000-93105 |
| Dual Binnacle Kit | 67000-93115 |
| Flush Mount Kit | 67000-93126 |
| Remote Control Cables | 99105-11002-0XX* 2 req'd |
| Single Binnacle | 67200-93113 |
| Dual Binnacle | 67200-93123 |
| Flush Mount | 67200-93132 |
| Wire Harness 16' | 36620-93152 |
| Wire Harness 21' | 36620-93162 |
| Wire Harness 26' | 36620-93162 |
| Power Trim/Tilt Sw. | 37805-93100 |
| Ignition Sw. Panel Assy. | 37100-96100 |
| Dual Ign. Sw. Panel Assy. | 37100-96114 |
| Ing. Sw. Emg. Stop/Buzzer | 37100-96124 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93104 |
| Water Pump Repair Kit | 17400-96J02 |
| Drag Link Kit | 67701-96J00 |
| Propeller Hardware Kit | 57630-92E00 |
| Spark Plug | BKRE 09482-00427 |

SPECIFIC APPLICATION NOTES: * Cable is available in one foot increments from 8 to 25 feet. (example: 008 = 8 ft, 025 = 25 ft)
 ** Must use with one of the following Main Harnesses: 16': 36620-93152 21': 36620-93162 26': 36620-93162
 *** In-hood Electric Start Harness



APPLICATION CHART



| DF225/250 '04 - Current | |
|---------------------------|-----------------------------|
| Side Mount Control Box | 67200-93J50** '04 - Current |
| Single Binnacle Kit | 67000-93J05 |
| Dual Binnacle Kit | 67000-93J15 |
| Flush Mount Kit | 67000-93J26 |
| Remote Control Cables | 99105-11002-0XX* 2 req'd |
| Single Binnacle | 67200-93J13 |
| Dual Binnacle | 67200-93J23 '04 - Current |
| Flush Mount | 67200-93J32 '04 - Current |
| Wire Harness 16' | 36620-93J52 |
| Wire Harness 21' | 36620-93J02 |
| Wire Harness 26' | 36620-93J62 |
| Power Trim/Tilt Sw. | 37805-93J00 |
| Ignition Sw. Panel Assy. | 37100-96J00 |
| Dual Ign. Sw. Panel Assy. | 37100-96J14 |
| Eng. Sw. Stop/Buzzer | 37100-96J24 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93J04 |
| Water Pump Repair Kit | 17400-93J02 '04 - Current |

| | |
|------------------------|---------------------------|
| Drag Link Kit | 67700-93J00 '04 - Current |
| Propeller Hardware Kit | 57630-92E00 '04 - Current |
| Spark Plug | BKR6E 09482-00427 |



| DF150AP/175AP/200AP | |
|----------------------------------|-------------------|
| Single Engine First Station Kit | 67000-98J60 |
| Single Engine Second Station Kit | 67000-98JF0 |
| Dual Engine First Station Kit | 67000-98J60 |
| Dual Engine Second Station Kit | 67000-98JH0 |
| Triple Engine First Station Kit | 67000-98J49 |
| Triple Engine Second Station Kit | 67000-98J59 |
| Quad Engine First Station Kit | 67000-98J71 |
| Quad Engine Second Station Kit | 67000-98J80 |
| Flush Mount Station Kit | 67000-98J69 |
| Remote Control Assembly, Single | 67200-98J03 |
| Remote Control Assembly, Multi | 67200-98J13 |
| Remote Control Assembly, Flush | 67200-98J22 |
| Panel Assembly, Single | 37100-98J11 |
| Panel Assembly, Dual | 37100-98J21 |
| Panel Assembly, Triple | 37100-98J31 |
| Main Power Key Switch Assembly | 37100-98J04 |
| Panel Assembly, Emergency Stop | 37803-93J04 |
| Warning Buzzer | 38500-92X50 |
| Water Pump Repair Kit | 17400-96J02 |
| Gear Case Seal Kit | 25700-93J00 |
| Drag Link Kit | 67701-96J00 |
| Propeller Hardware Kit | 57630-92E00 |
| Spark Plug | BKR6E 09482-00427 |
| Spark Plug (DF200A) | 09482-00649 |



| DF250SS '08 - Current | |
|------------------------|--------------------------|
| Side Mount Control Box | 67200-93J50** |
| Single Binnacle Kit | 67000-93J05 |
| Dual Binnacle Kit | 67000-93J15 |
| Flush Mount Kit | 67000-93J26 |
| Remote Control Cables | 99105-11002-0XX* 2 req'd |
| Single Binnacle | 67200-93J13 |
| Dual Binnacle | 67200-93J23 |
| Flush Mount | 67200-93J32 |
| Wire Harness 16' | 36620-93J52 |
| Wire Harness 21' | 36620-93J02 |
| Wire Harness 26' | 36620-93J62 |

| | |
|---------------------------|-------------------|
| Power Trim/Tilt Sw. | 37805-93J00 |
| Ignition Sw. Panel Assy. | 37100-96J00 |
| Dual Ign. Sw. Panel Assy. | 37100-96J14 |
| Eng. Sw. Stop/Buzzer | 37100-96J24 |
| Warning Buzzer | 38500-92X50 |
| Emergency Stop Assy. | 37803-93J04 |
| Water Pump Repair Kit | 17400-98J01 |
| Drag Link Kit | 67700-93J00 |
| Propeller Hardware Kit | 57630-92E00 |
| Gear Case Seal Kit | 25700-98J00 |
| Spark Plug | BKR6E 09482-00427 |



| DF250AP/300/300AP | |
|----------------------------------|--|
| Single Engine First Station Kit | 67000-98J60 |
| Single Engine Second Station Kit | 67000-98JF0 |
| Dual Engine First Station Kit | 67000-98J60 |
| Dual Engine Second Station Kit | 67000-98JH0 |
| Triple Engine First Station Kit | 67000-98J49 |
| Triple Engine Second Station Kit | 67000-98J59 |
| Quad Engine First Station Kit | 67000-98J71 |
| Quad Engine Second Station Kit | 67000-98J80 |
| Flush Mount Station Kit | 67000-98J69 |
| Remote Control Assembly, Single | 67200-98J03 |
| Remote Control Assembly, Multi | 67200-98J13 |
| Remote Control Assembly, Flush | 67200-98J22 |
| Panel Assembly, Single | 37100-98J11 |
| Panel Assembly, Dual | 37100-98J21 |
| Panel Assembly, Triple | 37100-98J31 |
| Main Power Key Switch Assembly | 37100-98J04 |
| Panel Assembly, Emergency Stop | 37803-93J04 |
| Warning Buzzer Assembly | 38500-92X50 |
| Water Pump Repair Kit | 250AP 17400-98J02 300/300AP 17400-98J01 |
| Gear Case Seal Kit | 25700-98J00 |
| Drag Link Kit | 67700-93J00 |
| Propeller Nut Kit | 57630-92E00 |
| Spark Plug | BKR6E 09482-00427 |

SPECIFIC APPLICATION NOTES: * Cable is available in one foot increments from 8 to 25 feet. (example: 008 = 8 ft, 025 = 25 ft)
 ** Must use with one of the following Main Harnesses: 16': 36620-93J52 21': 36620-93J02 26': 36620-93J62
 *** Under-hood Electric Start Harness