# SUZUKI PRECISION CONTROL

04 | 05

Suzuki's flagship 300AP
4-stroke leads in power,
performance and technology.
The following are some
high-tech items to help take
advantage of Suzuki's leading
edge technology.

Flush Mount SPC Box Only (Replacement Units)

67200-98J22 Flush Mount SPC Box only

Suzuki Precision Control (SPC)
Electronic Throttle and Shift Systems
For DF150AP/175AP/200AP/250AP/300AP

Single Engine SPC Box Only (Replacement Units)

67200-98J03 Single Engine SPC Box only



Dual/Triple/Quad Engine SPC Box Only (Replacement Units)

67200-98J13 Dual/Triple/Quad Engine SPC Box only

Single Engine SPC Kits				0.10
Single En	gine SPC Kits	67000-98J69 Flush-Mount Station Kit	67000-98JE0 Single Station Binacle Kit	67000-98JF0* Second Station Kit*
67200-98J03	Binnacle-Mount RC Box		1	1
67200-98J22	Flush-Mount RC Box	1		
37100 <del>-</del> 98J04	Main Power Key Switch Assy	1	1	
37100-98J11	Single Engine Control Panel Assy	1	1	1
38500-93J90	Warning Buzzer	1	1	1
37803-93J04	Emergency Switch Panel			1
36625-98J10	Battery Lead	1	1	
36770-98J11	Boat Control Module (BCM)	1	1	1
36775-98J00	BCM Holder (L)	1	1	1
36776-98J00	BCM Holder (R)	1	1	1
33911-88BL0	BCM-Connect Cap	1	1	1
33925-93J00	BCM Cushion	1	1	1
36623-98J20	BCM #1 Wiring Harness	1	1	
36624-98J02	BCM #2 Wiring Harness			1
36622-98J00	Dual Station Main Harness			1
33926-98J00	Terminal Resistor	2	2	
37860-87L00	Troll Mode Switch Panel	1	1	1

\*Order Single Station Kit in addition to Second Station Kit to complete

Dual	Engines	SPC	Kits	
------	---------	-----	------	--

		67000-98JG0 Single Station Kit	67000-98JH0* Second Station Kit*
67200-98J13	Dual Binnacle-Mount RC Box	1	1
37100-98J04	Main Power Key Switch Assy	1	
37100-98J21	Dual Engine Control Panel Assy	1	1
38500-93J90	Warning Buzzer	1	1
37803-93J04	Emergency Stop Switch Panel		1
36625-98J10	Battery Lead	1	
36770-98J11	Boat Control module (BCM)	1	1
36775-98J00	BCM Holder (L)	1	1
36776-98J00	BCM Holder (R)	1	1
33925-93J00	BCM Cushion	1	1
36623-98J30	BCM #1 Wiring Harness	1	
36624-98J11	BCM #2 Wiring Harness		1
33926-98J00	Terminal Resistor	2	
36621-98J00	Dual Engine Single Station Harr	ness 1	
36622-98J00	Dual Station Main Harness		1
37860-87L00	Trojj Mode Switch Panej	1	1

\*Order Single Station Kit in addition to Second Station Kit to complete

#### Triple Engines SPC Kits

		67000-98JJ0	67000-98JK0*
	S	ingle Station Kit	Second Station Kit*
67200-98J13	Dual Binnacle-Mount RC Box	1	1
37100-98J04	Main Power Key Switch Assy	1	
37100-98J31	Triple Engine Control Panel Assy	1	1
38500-93J90	Warning Buzzer	1	1
37803-93J04	Emergency Switch Panel		1
36625-98J10	Battery Lead	1	
36770-98J11	Boat Control module (BCM)	1	1
36775-98J00	BCM Holder (L)	1	1
36776-98J00	BCM Holder (R)	1	1
33925-93J00	BCM Cushion	1	1
36623-98J30	BCM #1 Wiring Harness	1	
36624-98J11	BCM #2 Wiring Harness		1
33926-98J00	Terminal Resistor	2	
36621-98J10	Triple Engine Single Station Har	ness 1	
36622-98J00	Dual Station Main Harness		1
37860-87L00	Troll Mode Switch Panel	1	1

\*Order Single Station Kit in addition to Second Station Kit to complet

## Quad Engines SPC Kits 67000-98J71

		67000-98J71 Single Station Kit	67000-98J81* Second Station Kit*
67200-98J13	Dual Binnacle-Mount RC Box	1	1
37100-98J04	Main Power Key Switch Assy	1	
37100-98J21	Dual Engine Control Panel Assy	2	2
38500-93J90	Warning Buzzer	2	2
37803-93J04	Emergency Switch Panel		1
36625-98J10	Battery Lead	2	
36770-98J20	Boat Control module (BCM)	2	2
36775 <b>-</b> 98J00	BCM Holder (L)	2	2
36776-98J00	BCM Holder (R)	2	2
33925-93J00	BCM Cushion	2	2
36623-98J40	BCM Quadruple Wiring Harness	1	1
33926-98J00	Terminal Resistor	4	
36621-98J00	Dual Engine Single Station Harr	iess 2	
36622-98J00	Dual Station Main Harness		2
37860-87L00	Troll Mode Switch Panel	1	1

\*Order Single Station Kit in addition to Second Station Kit to complete

### Counter Rotation Adaptor

36612-98J10 Regular Rotation Selector 36612-98J20 Counter Rotation Selector



SUZUKI PRECISION CONTROL

Suzuki's flagship 300AP 4-stroke leads in power, performance and technology. Following are some high-tech

items to help take advantage of Suzuki's leading edge

For 150AP/175AP/200AP/250AP/300AP





### **Emergency Stop Switch Panel Assembly**

Includes: Emergency Stop Switch with Panel and Lanyard. Required at each station.

37803-93J04 Emergency Stop Switch Panel Assy

#### Control Panel Assemblies

Single to multiple engine, single or second station, select the panel needed for your application. Requires Main Switch Assembly 37100–98/03.



#### Triple Engine Control Panel Assy

37100-98J31 Triple Engine Control Panel Assy



#### Main Power Key Switch Assembly

Main Power Key Switch required for use with switch control panels listed above. Includes key.

37100-98J04 Main Power Key Switch Assembly





#### **Dual/Quad Engine Control Panel Assy**

37100-98J21 Dual Engine Control Panel Assy 37100-98J21 x2 Quad Engine Control Panel Assy

**Battery Lead** 



#### **Battery Isolator Lead Sets**



### Wiring Harnesses

Main Wiring Harness. Order length as needed for rigging applications.



A HITCHIST

36620 <b>-</b> 98J30	21' (6.5m) Wiring Harness
36620 <del>-</del> 98J40	31' (9.5m) Wiring Harness



36620-98J50 6.5" (2m) Wiring Harness Extension (Optional; order as needed)



#### Single Engine Control Panel Assy

37100-98J11 Single Engine Control Panel Assy

# Replacement Wiring Harness (not shown)





### **BCM Harness**

BCM Harness No1 for Single Engine Single Station BCM Harness No1 for Multiple Engines Single Station 36623-98J20



36624-98J02	BCM Harness No 2
	for Single Engine Second Station
36624-98J11	BCM Harness No 2
	for Multiple Engine Second Station
36623-98J40	BCM Quadruple Harness

# SUZUKI CONTROL BOXES

Suzuki Genuine Control Boxes are designed for longevity and ease of use. Choose a control box that fits your application. We offer Single Binnacle Control Box for your top of the line Suzuki Outboard, or choose a Dual Binnacle Control Box to manage 2 Suzuki Outboards masterfully. Suzuki Genuine Control Boxes define accuracy, user-friendliness, and durability.





#### Replacement Control Boxes

67200-88L00	Single Binnacle Control Box	'05 - Current
67200-88L10	Dual Binnacle Control Box	'05 - Current
67200 <del>-</del> 93J33	Flush Mount Control Box	'05 - Current



Single Binnacle Control Box uses a convenient thumb-operated power trim and till switch, pust-button shifting disengagement for faster warm ups and built-in neutral safety switch. Kit includes timen isted: "Main Wining Harness must be ordered separately, see below.

67000-88L00 Single Binnacle Control Box Kit includes:
37100-96124 Ignition Switch Panel with Emergen 67200-88L00 Single Binnacle Control Box Asse Ignition Switch Panel with Emergency Stop and Warning Buzzer Assembly Single Binnacle Control Box Assembly



7000-88L10*	Dual Binnacle Control Box Kit
rcludes:	
7100-96J14	Dual Ignition Switch with Emergency Stop
8500-92X50	Warning Buzzers (2)
7200-88L10	Dual Binnacle Control Box Assembly



37000-93J27*	Flush Mount Binnacle Control Box Ki
ncludes:	
37100-96J24	Ignition Switch Panel with
	Emergency Stop and Warning
	Buzzer Assembly
37200-93J33	Flush Mount Control Box

38500-92X50	Warning Buzzer. Replacement
	for DF models.
36620-93J20	Control Box Adaptor Harness, Adapts
	2005+ model control box with
	square connector to 2004 and earlier
	motors with round connector.
36620-93J30	Control Box Adaptor Harness
	Adapts 2005+ model engine with
	square connector to 2004 and
	earlier harness with round connector







Side Mount Control Boxes can be tailored to your needs.

Standard features include a fast idle lever for easy warm-ups, a key-type ignition switch, and an emergency stop switch. "Main Wiring Harness must be ordered separately, see below.

67200-91J20	DF4/6	'03 - '10	
67200-89E35	DF9.9/15	197 - 104	
67200-94J20	DF9.9/15	105 - 110	
	DF8A/9.9A	'10 - Current	
	DF25 V-Twin	'06 - Current	
	DF25A/30A (NON PT or PTT)	'14 - Current	
67200-99E56	DF25/30 (W+W/O PT)	100 - 104	
67200-94J20	DF25/30	105 - 108	
67200-99E56	DF40/50	'99 - '04	
	DF60/70	'98 - '04	
67200-93J50	DF25A/30A (With PT or PTT)	'14 - Current	
	DF40/50	105 - 110	
	DF40A/50A/50AV/60A/60AV	'10 - Current	
	DF60/70	'05 - '10	
	DF70A/90A	'10 - Current	
	DF90/115/140	'05 - Current	
	DF150/175/200A	'06 - Current	
	DE200/225/250	'05 - Current	







